

Switches

Pendant Pushbutton Stations*PBS Series Parts and Accessories***Replacement Inserts**

When the insert switches are in need of replacement, simply unplug the old insert and plug in a new one.

Description	Catalog Numbers
Single speed insert momentary N.O. and N.C.	PG2
On-Off insert (no mechanical interlock) Momentary, start-stop, reset-stop.	PG6
3 speed insert, momentary. Used to a maximum of 3 speed points.	MS2
For five speed applications replace an existing terminal board with the TB5 terminal board and replace an existing insert with the five speed (MS5) insert.	
5 speed insert, momentary. Used to a maximum of 5 speed points.	MS5

Conversion Inserts

In addition to single speed and two speed applications, preassembled units can be adapted to handle other applications.

Description	Catalog Numbers
Terminal board Catalog No. TB2 is required for each insert switch PG2, PG6 and MS2.	TB2
Terminal board Catalog No. TB5 is required for insert switch MS5.	TB5

Accessories

Description	Catalog Numbers
Indicator labels for replacement package contains 1 each: hoist, trolley, bridge, forward-reverse, raise-lower, in-out, right left, east-west, north-south, reset-stop, start-stop, power, main hoist, aux. hoist, on-off, up-down.	PBSLP
Rubber button cover for replacement purposes.	PBSBC
120V red pilot light for 4, 6, and 8 button units only.	PBSPL1*

*Each pendant station can accommodate one of the pilot light in the 1.20" (30.6) diameter mounting hole.

Kellems® Deluxe Aluminum Cord Fitting

Outdoor or indoors where subject to moisture, splash or submersion. Kellems grips provide strain relief for multi-conductor cable.

Description	Cord Range	Catalog Numbers
Kellems grip.	.750-.875" (19 to 22.2)	07401023
Kellems grip.	.875-1.00" (22.2 to 25.4)	07401025

**PG2****PG6****MS2****MS5****TB2****TB5****PBSBC****PBSLP****PBSPL1****07401023**