


Fan Speed Controls Rated at 120VAC, 60Hz



YLFC700R
OD-SCV-2.5A

Important Notes

Please read before installing

1. Turn off circuit breaker prior to installing the fan speed control.
2. All wiring must be in accordance with all applicable National (NEC/CEC), state, and local codes.
3. Use copper wires only.
4. CAUTION: To avoid overheating and possible damage to other equipment, do not use to control receptacles, fluorescent lighting fixtures, or transformersupplied appliances.
5. Controls require separate wires in the wallbox for fan and light.
6. When no "ground means" exists within the wallbox, then NEC 404.9 exception to (b) allows a control without a ground connection, to be installed as a replacement. For this type of installation, cap or remove the green control ground wire. A control installed under this exception (NEC 404.9 exception to (b) must be provided with a plastic, noncombustible, UL listed wallplate.

(1)



Installation

1. Turning power OFF.

WARNING:

Risk of the SHOCK, FIRE or DEATH, turn power OFF at circuit breaker or remove fuse, and make sure the power is disconnected.

2. Single-pole wiring the fan speed control




3. Test fan speed control prior mounting in the wallbox

1. Restore power at the circuit breaker or fuse.
2. As shown on the following, turn the rotary knob slowly from left to right to control fan ON / OFF and speed.
3. To turn off fan completely, turn the rotary knob left until you feel the click.
4. **Risk of shock, fire or death, when you finish the test, turn off power again** until the installation is complete.

(2)

Rotary knob .



You feel a click close to "OFF" when you turn on fan speed control, or turn off completely.

4. Put fan speed control into wallbox, mounting screws

Push wires carefully into the wallbox, tighten screws, the installation complete.

5. Turning power ON

Turn power ON.

Warranty Information

If within one(1) year from the date of purchase, this product fails due to a defect in material or workmanship, we will repair or replace it, at its sole option, free of chare. This warranty does not apply to: (a) damage to units caused by accident, droppine or abuse in handline, acts of God or any neelient use; (b) units which have been subject to unauthorized repair, opened, taken apart or otherwise modified; (c) unit not used in accordance with instructions; (d) damaes exceedine the cost of the products. This warranty service is available by returnine the products with proof of purchase date and a description of the problem to dealer from whom the unit was purchase.

(3)